



File Name: carrier furnace manual.pdf

Size: 2324 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 5 May 2019, 23:32 PM

Rating: 4.6/5 from 661 votes.

Status: AVAILABLE

Last checked: 3 Minutes ago!

In order to read or download carrier furnace manual ebook, you need to create a FREE account.

Download Now!

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with carrier furnace manual . To get started finding carrier furnace manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

carrier furnace manual

Select Product Category Just enter the model number below, and we'll give you a list of links to all the documents associated with it. Rather than have you commit them all to memory, we made our model numbers easy to find. If you don't happen to have them handy, you'll also find the model number printed right on the unit. If your heat pump is geothermal, the model information should be easily found on the front of the unit. You should see the model number printed on ratingplate or decal. Still unable to find that model number. Just call your local Carrier Expert. He or she will be happy to help you. Make sure the temperature is set cooler than the current indoor temperature. If it is not running, make sure the breakers in your home's breaker box or electrical panel are in the ON position. Make sure it's in the ON position. If the system is set for cooling, the blower motor should be running. If not, check to make sure your indoor unit switch is in the ON position. If you have oneinchthick furnace filters, a onceamonth change is recommended. If you don't change it, the filter will eventually block the proper airflow and cause your outdoor air conditioner unit to shut down. Return air grilles are larger and are located on a wall or the ceiling in newer homes. Older homes frequently have return air grilles on the floor. NOTE If your system control has a "Constant ON" feature, you will not always feel warmth, even though air may be blowing. If it isn't, your system won't know to provide heating. Try turning the fan to ON using the fan switch on the control or thermostat to test for power to the furnace. If you have oneinchthick furnace filters, a onceamonth change is recommended. If you don't change it, the filter will block the proper airflow and strain your furnace. Return air grilles are larger and are located on a wall or the ceiling in newer homes. Older homes frequently have return air grilles on the floor. <http://ivankotov.ru/img/lib/bose-companion-3-multimedia-speaker-system-manual.xml>

- **carrier furnace manual, carrier furnace manual pdf, carrier furnace manuals online, carrier furnace manual reset, carrier furnace manual reset limit switch, carrier furnace manual troubleshooting, carrier hvac manual, carrier hvac manuals download, carrier hvac manual pdf, carrier furnace specs, carrier furnace manual, carrier furnace manual, carrier furnace manuals downloads, carrier furnace manuals pdf, carrier furnace manual reset limit switch, carrier furnace manual, carrier furnace manual pdf, carrier furnace manuals downloads, carrier furnace manual reset limit switch.**

NOTE If your system control has a "Constant ON" feature, you will not always feel warmth, even though air may be blowing. Verify that the circuit breakers are ON or that fuses have not blown. If you must reset breakers or replace fuses, do so only once. Contact your Carrier expert for assistance if the breakers trip or the fuses blow a second time. Check air filters for accumulations of large particles. Check for blocked exhaust air grilles or ductwork. Keep grilles and ductwork open and unobstructed. Defrost time could be five to 20 minutes, depending on temperature and settings. With this information, the dealer will be able to correct any problems. Make sure that the condensate drain tube has a slight slope and is not kinked. Provide your model and serial number. With this information, the dealer will be able to correct any problems. Water likely means the support base has shifted since installation and is no longer level. Soak the core in warm water and mild soap for three hours and then rinse under warm not hot water. Use a vacuum cleaner to remove accumulated dust and then handwash in warm water. Filter life varies from home to home and is based on several factors, but most last from eight to 12 months. If your geothermal unit is connected to well water instead of a closed loop, we recommend the heat exchanger inside the unit be cleaned

periodically to prevent the buildup of minerals that can reduce system performance. VariabMeCapacity. Condensing. DkectVent. Gas FurnaceFor Sizes 040 120. ReadSeriesIndex. PageInstalledFurnacesDO NOT connectDownflow. StepFurnaces. The returnair. TheCteanable. Filters may be field modified by cutting filter material and support rods 3 inTable 92 NFPA 542002.Gas valveHh,FailureNever purge a gas line into a combustionUse a commerciallyA failureFuter Arrangement. UseFailureCapped.<http://old.gmina-klucze.pl/obrazki/bose-companion-3-series-2-instruction-manual.xml>

PlaceThen connectIf a flexibleAn accessiblePanelFailure to follow this cautionTrap can beInstall a sedimentMUST be installedFigAlso,Refer to rating plate or TableMakeElectrical. Gas Pipe Arrangement. PipingIf pressureElectricalFieldsuppliedAfier all connectionsCheckProperNo componentFailureThis may consistFailureDo notRelocationJboxJbox.TaMe 4ElectricalNationalBlowerA disconnectingThe cabinetConnections. See Fig. 28 for field wMngStepSee Table 4 fbr wire sizeUse a separateCode CSATheIf test pressureStatesCodeJi.Use W2 with 2stage thermostat when zoning. If any of the original wire, as supplied, must be replaced, useApplication. WiringDiagramTheFor additionalNo.Do notSwitchFailureFailure to Jbllow this cautionAny electrical shorts of 240v wiring during installation, service, orAir leaner. The tarnaceConnectElectronicFailureAir leanerThe terminalsTheThe HUMZone Controller orTheInI ventingI fitrnaceAn improperlyPlaceVentGas and PropaneNaturalUse the flameAdjustDoDeterleakage,Turn on any exhaustVentingStepInstallationPropaneZ223A NFPA 54 or the SA B149.1. Natural Gas andFor anyElectronic Air Clea net ConnectionElectroNc AirCleaner Connection Common. Rarne Rollout Switch Man Reset SPSTNC Factory Installed. Gas. Flame. Proving Sensor Electrode. Gas Valve Relay OPSf NOPressure. Swath. Light Gas. Emitting. DiodeCodes. Low Heat Pressure Switch SPSTNC. Limit Switch Auto Reset,SPSTNC. Printed. Cimuk BoardConnectorManual Switch Status Code Recall SPSf N O . ManuaISwitdl. Low Heat Only SPSTNO. Manual Switch Low Heat Rise Adj SPSTNO. ManuaISwitchAir. Conditioning Relay. SPSI N JumperRelay SPDTSW1 78 Manual Switches Blower OffDelay SPSTNOThisWhenCenterFailureSchedule40Schedule40Solvent. Cement. For ABS. Schedule40. Solvent. CementFittingsFittingsSchedule40PipeDWV at Schedule40Cement. For CPVC. Cellular Core DWV at Schedule40. Primer.

CombustionCellular Core Schedule40LocateExcessiveSolventAvoidAllFailureUseKeepFailure to fblow this warningThe minimumTheseCombustionAirTablePick thePipe DiameterAll pipe jointsSee shadedDo not countCombustionAirAn 080o14 size filrnace located in Indianapolis, elevafionIPS sizes. For PVCIPS sizesTheseDo not use pipe size greaterClearanceDescriptionCanadianPermittedInstallafion. CodeFor clearancesNotesWhere condensateWhen locafing vent terminations, consideration must be given to prevailing winds, location, and other conditions which may cause recirculation. Recirculafion can cause poor combustion, inlet condensate problems, and accelerated corrosion of the heat exchangers.TheA pluggedFig. 33CombustionAirTransition Location and Elbow ConfigurationSelect 1 vent pipe connection andBreakageThis tube shouldNOTE Select 1 vent pipe connection andThisIf use of this drain connectionEnsureNoRTV sealant,ClampFailmeVent pipe must be installedA 2in. Make. FailureInsertIumaceTightenConnectionsVent 8 to 8 Ft SystemCombustionair and vent pipes must terminate outside structure. AFour temainationBe sure pipe is fully inserted into fitting socketA continuous bead of cementNOTE Shaded parts in Fig. 37, 3g, 39, 40, and 41 are consideredConcentricConcentricConcentricConcentricSeeTerminationConcentricConcentricConcentricConcentricConcentricType. Pipe DiameterConcentricConcentricConcentricConcentricConcentricConcentricSize. Termination. Type. Pipe Diameter. TypeConcentricConcentricConcentricConcentricConcentricConcentricConcentricUnit. SizeSizeContinued. PiPE DIAMETERConcentricConcentricConcentricConcentricConcentricConcentricSize.

TerminationTypeConcentricConcentricConcentricConcentricConcentricConcentricSize. Pipe DiameterConcentricConcentricConcentricConcentricConcentricConcentricNANot AHowed; pressure switch will not makeFor applicationsConcentricSidewallExposed. SidewallTerminationPipeTerminationFig. 36IntakeFig. 40Instal! bracketFig. 39Concentric. RoofTerminationTermination. SideFig.

41SidewallTerminationSeparationVent and CombustionAirVent and CombustionAirRoofSideTermination of 12 in. or Less. Maximum Separation. Fig. 46Sidewall. Termination of More Than 12 in. Maximum SeparationPipe lengthStepPipesDrainCondensateCondensateAn externalThe field drain connection condensateCheckUnit mustTheTheAirCautionSee ServiceInstructionsMaintenanceAll. See Fig 48 ibr example of possible field drain attachmentOutdoorTo avoidDue to corrosivePrimer must conformFurnacePVC drain pipe,WhenExcessiveFurnaceTheseFig. 48ExamNeBefore operating furnace, check flame rollout manual reset switchIf necessm% press button to reset switch.Step. See InstallationSetupInstructions. TheSwitchPositionsTo set the desiredIf fieezeCorrectThis switchNOT jumperIfWireAidCF setupThisToThe furnaceHeat TapeTrapFig. 49CondensateReplacePositionChartCondensate. Trap. With. Water. CondensateFig. 52jPositionRise AdjustGasLines. If not previouslyThis compensatesStepIf modulatingWater should runStatus Code RecoveryTurn ON when using 2 stage. Heat ModeTurn ON for 400 CFM per ton. Turn OFF for 350 CFM per ton. Turn ON to initiate Component SelfTest for troubleshootingTurn OFF when SelfTest is completed.ON or OFF. Control blower Off Delay timeON or OFF. Control blower Off Delay time. Table 10BlowerPosition. SETUP SWITCH SW1o7 AND SW18 POSITIONThe RPM is used to evaluate ventIf a power intelTuptionON period two seconds after power is restored, if theThe amber LED light wiltAfterWhen the highheat pressureTheHSI, and gas valveFurnace control must be grounded fbr proper operation, orControl is grounded through. Failure to fblow this caution will result in intermittent unitUsed in conjunction. Table 10This selection is based upon the storedNever purge a gas line into a combustion chamber Never testStepUsed in conjunction. TableTurn ON to decrease Low Heat airflow by 7 percent and High HeatOn 040 unit will decrease. LowHeat Airflow 11 percent and HighHeat Airflow 10 percent.

ComponentTurn ON to increase Low Heat airflow by 18 percent. Low Heat. Rise AdjustAdaptiveSetupWarm! SurfaceIgniterIgnitionLockout.CPU beginsTrialsForIgnitionCPU will repeat. LockoutTheThe HSI igniterFSE, the filrnaceHSI. Five secondsIgniterGV, the gas valveGV permitsSequenceWhenHSI is energizedG, R, etc..Housing. If flame. Drain TubeSpeedLow To HighWhenFromRtoW. HighWhenHeatTheIom towheat. To LowThe RPM. The blowerThisIf the filrnaceW circuitHPSR to close the NThe RPMFromON at highheatHighheat35CPU beforeTrapLowheatd0BLWM is tarried ON at lowheatCondensateFig. 53FillingSimultaneously,The reductionIDM on high speed until flanm is noChangeIfHUM TheinducerTheEAI willSingleStage. In this mode. ThisON to selectFront. WI circuitHeatIfBLWM will tlanstionFront. W2 circuitR to. If starting up in towcooling,TheCoolingWhen. NmaceThe outdoorACR toHighcoolingWhenAiCThe electronicCF selectionWhenThe outdoorThermostat. JumperY1 to DHUMCoolingTheThe. The electronicIf theThe blowerWhenCPU determinesCPU can start up the coolingTheTheHighThisThe wall tlaermostatThe RPM isR toIf the power is interrupted,Low To HighThe air conditioningCoolingThe wal! themxostat. TheTwoSpeedThis selectionTheNmaceYlandY2R to Y1 circuitHighcoolingThe outdoor unit stops,FactoryDuringON untilTheDHUM input is mined ON when no dehumidify demand exists. Once 24 vac is detected by the furnace contlol on the DHUM. DHUM input is low for more than 48 hours, the furnace controlThe blowerWhenIn highheat,The exceptions are listed belowWhenContinuousTo selectSpeedSelectionThermostatThe furnace contlol CPU will shiftWhenWheneverIf youWiWICPU will transitionThe blowerIf both the Y1 and. YY2 signals disappear at the same time, the blower motor BLWMAAt the endTurnON fbr 15 seconds. TheSee Smwice LabelInstructionsOFF and then back ON. StepFurnaceRemoveMoveTurnAdjustFurnaceTableIt, use USAFor Canadian altitudes of 2000Table

11. NOTE If orifice hole appears damaged or it is suspected to have a burr free and squarely remove it.

After the component adjust manifold the component to initiate the component specific gravity orifice No. 450 is still energized, heating NOTE Be sure all pressure robing, combustion air and vent See notes 1, 2, 4, 6, 7, 9, 10, 11, 12. See notes 1, 2, 3, 4, 6, 8, 9, 10, 12, 13, Furnace with Two Speed Air Conditioner Heat Thermostat With Two Stage See notes 1, 2, 4, 11, 14, 15, and 16 Furnace and Single Speed Heat Pump Fig. 59 Dual Fuel Thermostat. Furnace and Two Speed. Fig. 61 Single Stage. Thermostat. With Two Stage. Furnace and Two Speed Air Conditioner. Heat Pump Air Temperature Installation. Sensor No. 1 No. Option Sensing If wire is connected, If wire is connected, No. No. 2 on Thermostat This is factory D on Dual Fuel Thermostat This is internally This is factory D on Dual Fuel Thermostat The thermostat Electronic If temperature This practice Temperature SIZE OF TEST DiAL Determine Ta Ne 13 Gas In this Furnace Operation Btu heating Furnace Check If either a status code 31 or 32 is flashed when inducer motor This section Startup Put away Reinstall By using The Controls Safety. Reset Users. Manual Brain. Heating Load Btu. Unit Level or Pitched Forward. Cooling Load Btu. Internal Tubing Connections Furnace Model Selection Sloped Free of Kinks. Leak Tight and. Location. Condensate. Trap Primed before Start Up. Roof or Sidewall. Heat Tape Installed if Required. Kit 2 Pipe or Concentric. Combustion Air. CBECKMBTBTARToUp. Pipe Length. Gas Input Rate Combustion Air. Pipe Elbow Quantity. Vent Pipe Length. Temperature. Rise Adjusted. Anticipator. Vent Pipe Elbow Quantity. Anticipator Setting Adjusted or. Pipe Diameter Determined Cycle Rate 3 Cycles per Hr Selected. Pipe Sloped To Furnace. Safety Controls. Check Operation. Pipe Insulation. Primary Limit. Over Ceitings. Pressure Switches. Low Ambient. Exposed Pipes Catalog No Form Pg 52 Replaces File Type Extension pdf. PDF Version 1.2. Linearized No. Page Count 52. Page Layout Single Page. Page Mode Use None. Producer Goby Monitor Application version 3, 2, 1, 4.

Create Date Fri Apr 20 15:14:02 2007. Author. Title. Subject. Sizes 060120, Series 110. Visit www.Carrier.com Please retain these instructions Special Venting Requirements. Consignes Installation B149 code. Vent systems must be composed The special vent In Canada, the primer and cement Primer, Purple Violet for Flue Gas Venting and. IPEX System 6361 U installation Au Mauve. Violette Follow the manufacturers The safe operation, All fire stop and roof flashing used with this Acceptability Under this standard, The Bien U acceptance Canadien. CSA B419 est Le Canadien Les Notice Installations Chapter In addition, It shall be the responsibility The state or local gas inspector of the side wall horizontally The following NFPA 54 as adopted by the Board; and Not Required The sign shall read, in print size no less than one half When Approved For questions Approved Street. Boston, Duct Systems. Acoustical Duct. Gas Piping and Gas Pipe Pressure Testing. Electrical Connections Applications Applications. Horizontal. Left Supply Air. Horizontal Right Supply Air. Discharge Installation Mode. Component. Self Test Furnace Heat Anticipator RIGHT AIR! O w Orientations Drain. Condensate Vent Systems. Application. Condensation Electrical Connections Condensate. Blower. Mode Set Temperature Common. Furnace. Restart Accessories Air Ducts. Air Connections. Mode General Requirements. Ductwork. Acoustical. Heating Supply. Return With Two Stage Hazardous. Locations Blower Two Stage. Continuous Mode. Cooling Mode Mode Two Stage Consult The qualified Application This furnace Refer to the individual Wear safety glasses, protective Read these Consult local. Code NEC Fuel Gas. Electrical Installation Gas and Propane. Codes, and Canadian Electrical. Code CSA C22.1. Recognize This is the safety alert. When you see this symbol on Understand Standards These words are used with the safety alert NOTE is used This Remove Return air Minor modifications Multipoise. Category. IV, condensing Always Air and Vent Pipe Systems Combustion Connect Combustion. Air and Vent Piping sections of these instructions.

Never Always Use a commercially RISE section of these instructions Gas Fired, Install this furnace only in a location and position as specified A return air duct is provided, Sheet metal parts may have sharp

edges or burrs. Use care. For a gas-fired furnace for installation. Locations. Failure. This. The. When. Failure. This furnace SHALL NOT be installed directly on carpeting. In Canada, special base is not required when this furnace is installed on the. Consult a qualified installer, service agency, or. See Fig. 3 for required. Follow all safety codes. Have. AGA and CGA design certified. Btu/h. It also prevents the entrainment of. This furnace is shipped with the following materials to assist in. These materials are shipped in the. Installer Packet includes. Installation, Startup, and Operating Instructions. Service and Maintenance Instructions. Users Information Manual. Warranty Certificate. Quantity. Vent and combustion air. Combustion air. Power entry hole filler plug. Vent Pipe Extension. The furnace shall be installed so that the electrical components. For accessory installation detail, refer to the accessory installation Z223.12006 and the Installation Standards, Warm Air Heating. Propane Installation Code NSC/NPIC CSA B149.105. Loose Parts Bag includes. Pressure tube extension. The installation. In absence of local codes, the. In the United States and Canada, follow all codes and standards. Remove all shipping materials before operating furnace. Step 2 General. Installation. For copies, contact the. National Fire Protection Association Inc., Batterymarch Park. Quincy, MA 02269; or for only the NFGC contact the. American Gas Association, 400 N. Capitol, N.W., Washington. Title 24 CFR, Part 3280, or when this standard is not. Mobile Homes.

CSA International, 178 Rexdale Boulevard, Etobicoke. Drawing. This forced air furnace is equipped for use with natural gas at altitudes 0 10,000 ft 0 3,050m, except 140 size furnaces are only approved for altitudes 0 7,000 ft. An accessory kit, supplied by the manufacturer, This furnace is for indoor installation in a building constructed. This furnace may be installed on combustible. Inches Clearance. To Combustible. Construction. Refer to the installation instructions for parts list and method of installation. In the US this furnace is for use with. In Canada, refer to installation instructions. Construction. Utiliser une trousse de conversion, Cette fournaise à air pu ne peut être installée dans une maison. Cette fournaise. Minimum. En Pouces Avec. EI6ments. De Construction. Combustibles. Cette fournaise. Aux. Etats Unis, cette fournaise. Au Canada, referer aux instructions. HORIZONTAL installations. ALL POSITIONS. Minimum. 1 inch back. For installation on combustible. Part No. CAR, CAP, CNPV, CNRV or Coil Casing, Part No. KCAKC. Clearance. Orientation de la. POSITIONS. Si. Line contact. Pour les fournaises. Vent clearance. To. Pour les fournaises. Combustion Air. Step 6 Gas Piping. Venting Contractors. Association. Refrigeration, HVAC Systems. Contractors. Association. Step 5 Acoustical Handbook. Chapters. Engineers. Chapter 34 or 2000. Parts. Glass Duct. NFPA 90B as Lining and Fibrous. Testing. D, Sheet Metal and Air Conditioning. National. Air Conditioning. Step 4 Duct Systems. Systems. Clearance. in inches. D6. gagement. pc. Step 3 Combustion. Society. Pour l'installation sur le plancher combustible. Ensemble. POUR LA POS. MON HORIZONTAL. Step 7 Electrical. Electrical. Canadian. Connections. Electrical. Chapters 12 and 13. Part 8 and Appendix C. The model 58MTB 4way multipoise, Gas Fired, Category IV, Local codes may require a drain pan under entire furnace and. Step 1 General. Fig. 4 Return Air. Temperature. Step 2 Upflow Applications.

In an upflow application, the blower is located below the burner. Electrostatic. Take precautions. Precautions. These precautions. Multiple disconnects. Tools held in. If the control is to be a factory supplied. See Condensate. Trap Tubing. Factory Shipped. Orientation section for drain tube. These tubes should be factory attached to condensate trap. These robes can be identified by their connection location. These tubes are. The condensate trap drain connection must be extended. In. Attach. Casing hole filler. If the alternate. Tubing. Upflow. Orientation. To relocate. See Condensate. Trap. Box Drain. Tube Connect. Failure to follow. Blower. Upflow. Tube. Access. Panel. Housing. Drain. Removed. Tube. Upper Inducer. Condensate. Housing Drain Connection. Refer. Condensate. Drain. Step 3 Downflow. Drain. NOTE See Fig. 6 or 7 or tube routing label on main furnace door. This cap is used to prevent. Ensure this connection. Port Tube. NOTE See Fig. 6 or 7 or tube routing label on main furnace door. Attached to the UPPER collector box drain connection. LOWER inducer housing drain

connectionThe LOWER collector box pressure tube pink label is factoryUpflow
ConfigurationProtectionApplications. In a downflow furnace application, the blower is located
aboveThe condensate trap must be removed from the factoryinstalledTo relocateTrapFig. 9
Downflow. InstallationTrap. Configuration. InstallationTube does not need to be cut.TubeTubeCasing
hole fillerRelocate robes as described below.LOWER inducer housing drain connection to theStep 4
Horizontal. ApplicationsTheDrainBox DrainTubeHousingDrainLOWER
inducerTubeCondensatePressure Switch connection labeled COLLECTOR BOX.ReferCasing hole
fillerFailure to followNOTE See Fig. 8 or 9 or robe routing label on main furnaceThe other collector
boxHigh Pressure Switch in DOWNFLOWRIGHT applicationsDrain. Discharge. In a horizontalRefer
to CondensateLeft TubeHigh. Pressure. SwitchCondensate.

ProtectionConstruct working platform where all required furnace clearancesThe LOWER collector
box pressure tube pink label is factoryThis tube MUST beNOTE See Fig. 10 or tube routing label on
main furnace door toModify tube as described belowThe condensate trap MUST be installed below
furnace. See. Fig. 5 for dimensions. The drain connection to condensate trapThis recommendation is
to reduce excessive condensate dropletsStep 5 Horizontal. Applications. Right SupplyAir. In a
horizontal right furnace application, the blower is located toLocal codes may require a drain pan
underTheConnection.