I'm not a robot

2009 Bose Corporation, The Mountain,Framingham, MA 01701-9168 USAAM324804 Rev.00 WAVE MUSIC SYSTEMOwners Guide | Bedienungsanleitung | Notice dutilisation | Manuale di istruzioni | Gebruiksaanwijzing324804 WMS cover.fm Page 1 Tuesday, July 28, 2009 12:58 PMPage 22To reduce the risk of fire or electrical shock, do not expose the product to rain or moisture.WARNING: The apparatus should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on the apparatus. As with any electronic products, take care not to spill CAUTION: To reduce the risk of electric shock, do not disassemble this product unless you are qualified. dangerous voltage within the system enclosure that may be of sufficient magnitude to constitute a risk of electrical The exclamation mark within an equilateral triangle, as marked on the system, is intended to alert the user to the To prevent electric shock, match the wide blade of the line cord plug to the wide slot of the AC (mains) receptacle. Insert fully.Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. The compact disc player should not be adjusted or repaired by anyone except properly qualified service personnel.Keep the remote control battery away from children. It may cause a fire or chemical burn if mishandled. Do not recharge, disassemble, heat above 100C (212F) or incinerate. Dispose of used batteries promptly. Replace only with a battery of the WARNING: No naked flame sources, such as lighted candles, should be placed on the apparatus.Please take the time to follow the instructions in this owners guide carefully. It will help you set up and operate your system properly and enjoy all of its advanced features. Please save this owners guide for future reference.This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be CLASS 1 LASER PRODUCTKLASSE 1 LASER PRODUKTLUOKAN 1 LASER LAITEKLASS 1 LASER APPARAT1994-2005 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission. All trademarks referenced herein are property of Bose Corporation. The WavePage 33Unpacking . . . . . 4Selecting a location . . . . . 4Connecting to power . . . . . 5Setting the clock . . . . . 6A Brief Introduction to Some Special Features . . . . . 7Introduction . . . . . 7Special Features . . . . . 7Remote control operating guide . . . . . 8Reading the display . . . . . 9Controlling the volume . . . . . 9Setting up automatic shutoff (Sleep) . . . . . 9Listening to FM/AM Radio . . . . . 10Turning the radio on . . . . . 10Tuning the radio . . . . . 10Storing a radio station to memory (Presets) . . . . . 11TALK RADIO mode . . . . . 11Playing Compact Discs . . . . . 12Playing audio compact discs (CDs) . . . . . 12CD Play Modes . . . . . 12Playing music file (MP3) CDs . . . . . 13Navigating through music files . . . . . 14Play modes for MP3 CDs . . . . . 14Setting and Using The Alarm . . . . . 15Setting the alarm . . . . . 15Waking to a radio station or CD . . . . . 15Setting the alarm time . . . . . 15Using the alarm . . . . . 16Stopping a sounding alarm . . . . . 16Turning alarm on and off . . . . . 16Snoozing an alarm . . . . . 16Connecting Other Equipment . . . . . 17Rear panel input/outputs . . . . . 17Connecting an external FM antenna . . . . . 17Using headphones . . . . . 18The set-up menu . . . . . 21Adjusting the snooze time . . . . . 22Changing the clock time format . . . . . 23Adjusting the display brightness . . . . . 24Setting the room code . . . . . 24Enabling the low-power mode . . . . . 25Performing a system reset . . . . . 25Cleaning . . . . . 26Replacing the remote control battery . . . . . 26Troubleshooting . . . . . 27Customer service . . . . . 27Limited warranty . . . . . 28Technical information . . . . . 28Index . . . . . 30Page 4Page 5Page 66music system is easily operated using the remote control. Just aim the remote at the front panel 1. Press and hold Time or Time + until 2. Press Time to adjust the displayed time backwards or press Time + to adjust the settings are stored in backup memory for up to 48 hours. This feature retains the systems Page 77We encourage you to begin by listening to the demonstration CD provided. Simply insert the Factory system settings have been set to satisfy most owners. If you wish to change the Dual tapered waveguides00.BWMS_UKE.book Page 7 Monday, July 27, 2009 3:49 PMPage 88Throughout this owners guide you will see button icons to the left of the operating Note: Pressing FM/AM, CD or AUX automatically turns on the WavePage 99ORmusic system on to that source. Pressing the AUX does not turn on an auxiliary source (such as your TV), so turn that on first.Press and hold Volume or to adjust the volume level. VOLUME - 0 (silent) to 99 music system. Press Mute again, or press Volume to unmute. To lower the volume before unmuting, press Volume while muted. After pressing Sleep, SLEEP - 30 MIN appears on the display and the sleep timer While the SLEEP setting is displayed, press Sleep again to set the sleep timer to Note: While in sleep timer set-up mode, if more than 10 seconds elapses between button Page 102009 Bose Corporation, The Mountain,Framingham, MA 01701-9168 USAAM324804 Rev.00 WAVE MUSIC SYSTEMOwners Guide | Bedienungsanleitung | Notice dutilisation | Manuale di istruzioni | Gebruiksaanwijzing324804 WMS cover.fm Page 1 Tuesday, July 28, 2009 12:58 PM2009 Bose Corporation, The Mountain,Framingham, MA 01701-9168 USAAM324804 Rev.00 WAVE MUSIC SYSTEMOwners Guide | Bedienungsanleitung | Notice dutilisation | Manuale di istruzioni | Gebruiksaanwijzing324804 WMS cover.fm Page 1 Tuesday, July 28, 2009 12:58 PMPage 22To reduce the risk of fire or electrical shock, do not expose the product to rain or moisture.WARNING: The apparatus should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on the apparatus. As with any electronic products, take care not to spill CAUTION: To reduce the risk of electric shock, do not disassemble this product unless you are qualified. dangerous voltage within the system enclosure that may be of sufficient magnitude to constitute a risk of electrical The exclamation mark within an equilateral triangle, as marked on the system, is intended to alert the user to the To prevent electric shock, match the wide blade of the line cord plug to the wide slot of the AC (mains) receptacle. Insert fully.Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. The compact disc player should not be adjusted or repaired by anyone except properly qualified service personnel.Keep the remote control battery away from children. It may cause a fire or chemical burn if mishandled. Do not recharge, disassemble, heat above 100C (212F) or incinerate. Dispose of used batteries promptly. Replace only with a battery of the WARNING: No naked flame sources, such as lighted candles, should be placed on the apparatus.Please take the time to follow the instructions in this owners guide carefully. It will help you set up and operate your system properly and enjoy all of its advanced features. Please save this owners guide for future reference.This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be CLASS 1 LASER PRODUCTKLASSE 1 LASER PRODUKTLUOKAN 1 LASER LAITEKLASS 1 LASER APPARAT1994-2005 Bose Corporation. No part of this work may be reproduced, modified, distributed or otherwise used without prior written permission. All trademarks referenced herein are property of Bose Corporation. The WavePage 33Unpacking . . . . . 4Selecting a location . . . . . 4Connecting to power . . . . . 5Setting the clock . . . . . 6A Brief Introduction to Some Special Features . . . . . 7Introduction . . . . . 7Special Features . . . . . 7Remote control operating guide . . . . . 8Reading the display . . . . . 9Controlling the volume . . . . . 9Setting up automatic shutoff (Sleep) . . . . . 9Listening to FM/AM Radio . . . . . 10Turning the radio on . . . . . 10Tuning the radio . . . . . 10Storing a radio station to memory (Presets) . . . . . 11TALK RADIO mode . . . . . 11Playing Compact Discs . . . . . 12Playing audio compact discs (CDs) . . . . . 12CD Play Modes . . . . . 12Playing music file (MP3) CDs . . . . . 13Navigating through music files . . . . . 14Play modes for MP3 CDs . . . . . 14Setting and Using The Alarm . . . . . 15Setting the alarm . . . . . 15Waking to a radio station or CD . . . . . 15Setting the alarm time . . . . . 15Using the alarm . . . . . 16Stopping a sounding alarm . . . . . 16Turning alarm on and off . . . . . 16Snoozing an alarm . . . . . 16Connecting Other Equipment . . . . . 17Rear panel input/outputs . . . . . 17Connecting an external FM antenna . . . . . 17Using headphones . . . . . 18The set-up menu . . . . . 21Adjusting the snooze time . . . . . 22Changing the clock time format . . . . . 23Adjusting the display brightness . . . . . 24Setting the room code . . . . . 24Enabling the low-power mode . . . . . 25Performing a system reset . . . . . 25Cleaning . . . . . 26Replacing the remote control battery . . . . . 26Troubleshooting . . . . . 27Customer service . . . . . 27Limited warranty . . . . . 28Technical information . . . . . 28Index . . . . . 30Page 4Page 5Page 66music system is easily operated using the remote control. Just aim the remote at the front panel 1. Press and hold Time or Time + until 2. Press Time to adjust the displayed time backwards or press Time + to adjust the settings are stored in backup memory for up to 48 hours. This feature retains the systems Page 77We encourage you to begin by listening to the demonstration CD provided. Simply insert the Factory system settings have been set to satisfy most owners. If you wish to change the Dual tapered waveguides00.BWMS_UKE.book Page 7 Monday, July 27, 2009 3:49 PMPage 88Throughout this owners guide you will see button icons to the left of the operating Note: Pressing FM/AM, CD or AUX automatically turns on the WavePage 99ORmusic system on to that source. Pressing the AUX does not turn on an auxiliary source (such as your TV), so turn that on first.Press and hold Volume or to adjust the volume level. VOLUME - 0 (silent) to 99 music system. Press Mute again, or press Volume to unmute. To lower the volume before unmuting, press Volume while muted. After pressing Sleep, SLEEP - 30 MIN appears on the display and the sleep timer While the SLEEP setting is displayed, press Sleep again to set the sleep timer to Note: While in sleep timer set-up mode, if more than 10 seconds elapses between button Page 102009 Bose Corporation, The Mountain,Framingham, MA 01701-9168 USAAM324804 Rev.00 WAVE MUSIC SYSTEMOwners Guide | Bedienungsanleitung | Notice dutilisation | Manuale di istruzioni | Gebruiksaanwijzing324804 WMS cover.fm Page 1 Tuesday, July 28, 2009 12:58 PMOwner's guide support: Use, set-up, mount, optimize, repair, find error codes, schematics, exploded views for : BOSE AWRCC5 > 1 1 Operating instructions, user manual, owner's manual, installation manual, workshop manual, repair manual, service manual, illustrated parts list, schematics.... Home - Advanced search - Help - All brands - All appliances - Selection - Download - Contact Terms of service - 2004-2024 Manuals Network Inc. Recent search for BOSE AWRCC5 :BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE AWRCC5 BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE 123 BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE ACOUSTIMASS 15 SERIES III BOSE AUDI TT BOSE AUDI TT BOYO (1) BOWE PASSAT (1) BOWE (25) BOULTER (5) BOSSTHERM (3) BOSS (29) BOSE (7) BOSCH (647) BORG WARNER (5) BOOST (6) BOONTON (4) BOOMBEAR (1) BONAIRE (8) BOMANN (2) BOMAG (8) BOMA (6) BOLENS (153) BOGO (1) BODY SCULPTURE (16) BODY POWER (1) BODUM (1) BOBCAT (50) Sorry to interruptCSS Error

How to clean bose wave music system. How much is a bose wave music system. Bose wave music system model awrcc5 manual. How does bose wave music system work. Bose wave music system awrcc7 manual. How to set up bose wave music system. Bose wave music system awrcc1 service manual. Bose wave music system awrcc4 bedienungsanleitung.