Continue

In today’s fast-paced digital world, keeping your devices running smoothly can sometimes feel like a full-time job. Whether your Samsung Tablet SM-T580 is lagging, crashing, or simply not performing like it used to, a factory reset can often restore its original performance. In this comprehensive guide, we will walk you through the step-by-step process of factory resetting your Samsung SM-T580 tablet, while also covering essential tips and tricks to safeguard your data before initiating the reset. Why You May Need to Factory Reset Your Samsung SM-T580 Before we delve into the how-to of resetting your tablet, it’s crucial to understand the reasons you might consider this option. Here are a few compelling reasons to perform a factory reset: Performance Issues: If your tablet is running slow or freezing, a reset can clear up accumulated data and improve responsiveness. Software Glitches: Persistent bugs or crashes may indicate a need for a complete system refresh. Preparing for Sale: If you’re selling your tablet or giving it away, a factory reset will erase your personal data, keeping your information safe. Forgotten Password: In cases where you can’t remember your device password, a factory reset can help you regain access. Understanding these reasons can help you make an informed decision on whether a factory reset is right for you. Essential Precautions: Backing Up Your Data Before embarking on the factory reset journey, it’s imperative to back up any important data on your tablet. A factory reset will erase everything on your device, including apps, files, and settings. To avoid losing critical information, follow these steps: Backing Up Data on Your Samsung Tablet SM-T580 Google Backup: Go to Settings > Accounts and Backup. Tap on Back up data. Ensure that the toggle for Back up my data is enabled. Samsung Cloud: Navigate to Settings > Accounts and Backup > Samsung Cloud. Sign in, and select what data you want to backup. Manual Backup: Attach your tablet to a computer and transfer important files manually to ensure they are safely stored. By taking these precautions, you can be assured that your valuable data will remain intact even after resetting your device. How to Factory Reset Your Samsung Tablet SM-T580: Step-by-Step Guide Now, let’s get to the crux of the matter: how to perform a factory reset on your Samsung SM-T580 tablet. You can execute this process using two primary methods: through the Settings or via Hardware Buttons. Method 1: Factory Reset through Settings This method is the most straightforward and involves navigating through the tablet’s settings. Step 1: Access Settings Turn on your Samsung Tablet. Locate the Settings icon (often depicted as a gear) and tap to open the menu. Step 2: Navigate to General Management Scroll down and select General Management within the Settings menu. Step 3: Select Reset Options Tap on Reset to view available reset options. Step 4: Choose Factory Data Reset Select Factory Data Reset. This will display information about what will be erased. Step 5: Confirm the Reset After reviewing the information, scroll down and tap on Reset. If prompted, enter your PIN or password for confirmation. Step 6: Final Confirm and Reset Tap on Delete All to initiate the factory reset. Your device will restart and begin the reset process. After the reset, your Samsung SM-T580 will return to its original factory settings, akin to a fresh out-of-the-box experience. Method 2: Factory Reset via Hardware Buttons In some situations, you might not be able to access the settings due to an unresponsive screen or software crashes. For such cases, you can perform a factory reset using hardware buttons. Step 1: Power Off Your Tablet Press and hold the Power button until the Power Off menu appears, then select Power Off. Step 2: Enter Recovery Mode Once the tablet is completely off, press and hold the Volume Up and Power buttons simultaneously. When the Samsung logo appears, release the Power button while continuing to hold the Volume Up button until you see the Android recovery screen. Step 3: Navigate the Recovery Menu Use the Volume buttons to navigate through the options. Highlight Wipe data/factory reset and press the Power button to select it. Step 4: Confirm the Factory Reset Navigate to Yes and confirm by pressing the Power button. The tablet will process the factory reset. Step 5: Reboot the Device Once the reset is complete, select Reboot system now. Your tablet will restart, and upon reboot, you will be greeted with the initial setup screen. Post-Reset: Initial Setup and Restoration Once the factory reset is complete, you will need to set up your Samsung Tablet SM-T580 from scratch. Step 1: Language and Connectivity Select your preferred language and connect to Wi-Fi. This step is crucial for restoring your data from backups. Step 2: Restore Your Data If you backed up your data previously, you could restore it during the initial setup: Choose Restore from Google Backup during setup. Log in to your Google account and select the backup to restore from. Troubleshooting Post-Reset Issues While factory resetting your device often solves numerous issues, there can be times when you face post-reset problems. Common Issues Unable to Restore Data: If your backup is not available, ensure you are logged into the correct Google account or Samsung account where the backup was originally stored. Performance Concerns: If the tablet is still lagging, it could indicate hardware issues rather than software. Consult a professional if problems persist. Conclusion Factory resetting your Samsung SM-T580 tablet can breathe new life into your device, resolving many performance issues and ensuring a clean slate for future use. By following the steps outlined in this guide, you can navigate the resetting process with confidence. Remember to always back up your important data before proceeding, and take advantage of tools like Google Backup and Samsung Cloud for a seamless restoration experience. With a refreshed tablet in hand, you can enjoy your digital content without the frustrating hiccups. Taking the time to understand and utilize your device effectively is crucial in today’s tech-driven world. Happy resetting! What is a factory reset and why would I need to perform it on my Samsung Galaxy Tab SM-T580? A factory reset is a process that restores your Samsung Galaxy Tab SM-T580 to its original factory settings, which means all data and settings will be erased. This action can be useful for several reasons, such as improving performance if your tablet has become sluggish, fixing persistent software issues, or preparing the device for sale or transfer to another user. Before initiating a factory reset, it is crucial to back up any important data you wish to keep, including photos, documents, and apps. Once the factory reset is complete, all information not saved to a backup will be permanently lost, making it important to take these precautions beforehand. How do I back up my data before performing a factory reset? To back up your data on your Samsung Galaxy Tab SM-T580, you can use Samsung’s built-in backup features. Navigate to the “Settings” app, scroll down to “Accounts and backup,” and select “Backup and restore.” From there, you can choose to back up your data to your Samsung account or Google Drive. Make sure to follow the prompts to ensure all files, including photos, app data, and settings, are backed up. Alternatively, you can also manually transfer important files to your computer or other storage devices. Connect your tablet to a computer using a USB cable, then copy and paste your files into a designated folder on the computer, ensuring you have everything you need before proceeding with the factory reset. What steps do I need to follow to perform a factory reset on my SM-T580? To perform a factory reset on your Samsung Galaxy Tab SM-T580, start by navigating to the “Settings” app on your device. Scroll down and select “General management,” then tap on “Reset.” You will see several reset options; choose “Factory data reset.” This will show you what data will be erased. Tap on “Reset” to proceed, and if prompted, enter your device’s PIN or password. After confirming your decision, tap on “Delete all” to initiate the process. The tablet will restart, and you will see a progress screen as the factory reset completes. Once it’s finished, your device will reboot to the initial setup screen, just like it was when first unboxed. Will a factory reset remove my Google account and all installed apps? Yes, performing a factory reset on your Samsung Galaxy Tab SM-T580 will remove your Google account along with all installed apps and their data. This means that after the reset, you will need to set up your device from scratch, including signing back into your Google account and reinstalling any apps you previously had on your tablet. To ensure that you can easily recover your apps and data after the reset, it’s recommended to note down a list of essential apps and ensure you have your Google account login information handy. Once your tablet is reset, you can access the Google Play Store to download your previously installed applications. How long does it take to complete a factory reset on the SM-T580? The duration of a factory reset on the Samsung Galaxy Tab SM-T580 typically takes a few minutes, but this can vary depending on the amount of data stored on the device. Generally, the process begins with the confirmation steps, followed by the actual reset, which usually completes within 5 to 10 minutes. However, if your tablet has a significant amount of installed apps and data, it might take slightly longer. After the reset process, your tablet will reboot, and you may need additional time to set it up again, depending on how much data needs to be restored from your backup or how long it takes to reinstall your apps. Be prepared to spend some extra time on the initial setup after the reset. What should I do if my Samsung tablet is unresponsive and I cannot access the settings to perform a factory reset? If your Samsung Galaxy Tab SM-T580 is unresponsive and you cannot access the settings, you can perform a hard reset using the hardware buttons. To do this, ensure your tablet is powered off. Then, press and hold the “Volume Up” button and the “Power” button simultaneously until the Samsung logo appears. Once the recovery menu appears, you can navigate using the volume buttons. In the recovery menu, use the volume buttons to scroll to “Wipe data/factory reset,” and confirm with the “Power” button. From there, select “Yes” to confirm the factory reset. This method will restore your tablet to factory settings, even if you cannot access the standard settings menu due to unresponsiveness. Just remember that all data will be erased in this process. Make sure you turned off your phone. Hold down the Power key, the Volume Up key and the Home Button for a while. Wait until the Samsung or Android logo appears. Release all the buttons. Now, you'll see... The device must be on. Go to the "Settings". In Settings choose "Backup & Reset". After that, go for "Factory data reset". Press "Reset device" to finish... First, download to your PC: Odin3 latest version, Firmware, Samsung Kies, and Samsung Drivers: Samsung Kies Odin3 latest version Samsung Drivers With the phone turned off press and hold the Volume down key, the... The first is :*#7353*#. Use this code to open the Quick Test menu that allows you to test different options of your device. The second is :*#0*#. Use this code to enter the General Test Mode where you can test... Turn on your device and open "Settings". In Settings select "About Phone". Click on "Build number" seven times and go back to "Settings". Finally, select Developer... The device must be switched on. Choose what you want to capture. Then press the Power key and the Volume down button at one time. Great! Now you have a new screenshot. Androidbiits.com will help you in performing a hard reset of Tab A (SM-T580, SM-T585N0). It comes with microUSB v2.0, accelerometer sensor, Bluetooth v4.2, 3.5mm audio jack, Wi-Fi Direct, Wi-Fi hotspot, 1080p video recording support, plastic frame, 16GB internal storage space, 8.2mm thickness, 2GB Random access memory and Exynos 7870 Octa processor. If you are facing any issue on your device, then you can use some simple steps to perform a factory reset. It may fix all issues available on your Tab A (SM-T580, SM-T585N0). Sometimes you might have forgotten the lock screen password of your device. You might have faced difficulty in using your Tab A (SM-T580, SM-T585N0). If your device is not responding, then hard reset is a good solution. Androidbiits.com will publish the step-by-step instructions using which you can perform a hard reset of Tab A SM-T580. Previously, I have published the simple instructions for performing a hard reset of Samsung Galaxy Tab A 10.1 SM-P585. Now, I will discuss about the step-by-step tutorial to perform a hard reset of Samsung Galaxy Tab A 10.1 SM-T580. I am expecting that you will be able to master reset Tab A (SM-T580, SM-T585N0) without any problem after reading the tutorial written in Androidbiits.com. Factory reset will remove all bugs from your phone. It will let you enjoy original factory settings on Tab A (SM-T580, SM-T585N0). Factory reset will also let you enjoy many other benefits. You should note that you don’t need root, unlock bootloader or TWRP Recovery to hard reset your device. The most important thing is that your device will not lose warranty after performing a factory reset. If you have forgotten the lock screen password of your Tab A (SM-T580, SM-T585N0), then you must perform a hard reset. It will let you bypass screen lock. You must save your private documents securely including messages and contacts before performing a hard reset of Tab A SM-T585N0, because all data will be deleted from your device after performing a hard reset. Below are the steps using which you can perform a hard reset of Tab A (SM-T580, SM-T585N0). Androidbiits.com will not be responsible if your device got broken during the process of factory reset. Tab A battery must be above 82 percentage before performing hard reset. You must follow these steps at your own risk. How to Factory Reset Samsung Galaxy Tab A 10.1 (SM-T580, SM-T585N0) Easily [Simple Steps] 1. First you have to turn off your Tab A 10.1. Then press Volume up button, Home button and Power button simultaneously to enter into Stock Recovery mode. 2. If you are facing difficulty in turning off your device, then press the power button and volume down button simultaneously on your Tab A (SM-T580, SM-T585N0). Release the volume down button as soon as your device turned off and immediately press Volume up button, Home button and Power button simultaneously. 3. Release Volume up button, Home button and Power button after you see Logo on screen. Your Samsung Galaxy Tab A (SM-T580, SM-T585N0) will enter into Stock Recovery mode after a few seconds. 4. Select “wipe data/factory reset” option. You can use volume button to select this option. 5. Use power button to confirm “wipe data/factory reset” option. 6. Select “YES” option using Tab A 10.1 volume button. Then, press power button to confirm this option. 7. You have to select “Reboot system now” option using volume button. 8. Press power button to confirm “Reboot system now” option. You have successfully performed a hard reset of Tab A (SM-T580, SM-T585N0). If you are experiencing any difficulty while performing hard reset of your Tab A, then don’t hesitate to share your issue with Androidbiits.com. Please submit your email address and subscribe to get more information regarding your Tab A 10.1. You must check your email to activate subscription. I’ll help you in performing a hard reset of your device. Want to know how to factory reset Samsung Galaxy Tab A 10.1 2016 WiFi T580? Or How to wipe all data on Samsung Galaxy Tab A 10.1 2016 WiFi T580? Or How to restore Samsung Galaxy Tab A 10.1 2016 WiFi T580 to factory defaults? The following tutorial shows all methods to master reset or hard reset Samsung Galaxy Tab A 10.1 2016 WiFi T580 and soft reset Samsung Galaxy Tab A 10.1 2016 WiFi T580. Samsung Galaxy Tab A 10.1 2016 WiFi T580 Hard Reset or Factory Reset is the process to restore software and system settings to factory defaults. This operation deletes all data, settings, passwords, apps and clears storage. It is recommended to backup data before proceeding to Hard Reset Samsung Galaxy Tab A 10.1 2016 WiFi T580. Samsung Galaxy Tab A 10.1 2016 WiFi T580 Factory Reset or Hard Reset is commonly used to repair a damaged or malfunctioning device, bypass or remove screen lock pattern/PIN/passcode on the device, fix software-related issues, software lag, or sluggishness, etc. It can also be used when selling the phone or tablet to wipe all the personal data and system settings.On the other hand, Samsung Galaxy Tab A 10.1 2016 WiFi T580 Soft Reset is commonly known as a reboot or restart. This operation doesn’t involve any loss of data and settings. It is usually carried out to fix device slowness or slow operation, software errors, memory errors, operating system errors, app errors, etc.Soft Reset clears RAM and temporary cache and gives your device a quick boost. Sometimes, the data stored in RAM and temporary cache gets corrupted; this results in App errors, OS errors, phone freeze, and other software-related issues. Thus, performing a Soft Reset solves most of the software problems with the phone. Also: Samsung Galaxy Note 4 S-LTE N916L Factory Hard ResetHow to Hard Reset or Factory Reset Samsung Galaxy Tab A 10.1 2016 WiFi T580Below are the methods that can help you factory reset or hard reset Samsung Galaxy Tab A 10.1 2016 WiFi T580. Factory Reset Samsung Galaxy Tab A 10.1 2016 WiFi T580 from SettingsOpen Settings on your phone. Scroll down and tap on Backup & Reset.Look for the Factory data reset option and tap on it.Now, tap on the RESET PHONE button and enter your Passcode or PIN. Now, select ERASE EVERYTHING to erase all your data, apps, and settings. Samsung Galaxy Tab A 10.1 2016 WiFi T580 Hard Reset from Recovery ModePower off your phone.Now, boot Samsung Galaxy Tab A 10.1 2016 WiFi T580 into Recovery Mode. When the device boots into Recovery, highlight the wipe data/factory reset option using Volume keys and select it using the Power button.Now, select the Yes -- delete all user data option and press the Power button to perform the operation.Now, all your data, apps, and settings will be deleted. When done, select the reboot system now option to reboot your device.Now, your Samsung Galaxy Tab A 10.1 2016 WiFi T580 is Hard Reset and restored to factory defaults.Note: After Samsung Galaxy Tab A 10.1 2016 WiFi T580 Hard Reset, you may be required to enter the previously used Google Account details when setting up the device. It is a security feature added by Google starting from Android 5.0 Lollipop, and this feature is called Factory Reset Protection (FRP). How to Soft Reset Samsung Galaxy Tab A 10.1 2016 WiFi T580To perform Soft Reset operation smoothly, press and hold the power button, select the Restart or Power OFF option, wait for 20-30 seconds, and power the device back ON. For Smartphones with removable batteries, Soft Reset can be performed by removing the battery and inserting it back again after a few seconds.In the case of a non-removable battery, when the device freezes, you can try to use a combination of keys along with the power button to power OFF your device. For example, Volume up + Power, Volume down + Power, Volume up + Volume down + Power, etc.Was this tutorial helpful? Do let us know in the comment section below. Consider sharing using the social buttons below. In a world where technology is constantly evolving, smartphones and tablets have become essential tools in our daily lives. However, sometimes these devices experience performance lags, bugs, or issues that may hinder your user experience. If you own a Samsung Tablet SM-T580 and wish to restore it to its original settings, you’re in the right place. This article will provide you with a detailed guide on how to reset your Samsung tablet—whether for troubleshooting purposes, preparing the device for resale, or simply giving it a fresh start. Understanding the Samsung Tablet SM-T580 The Samsung Tablet SM-T580, also known as the Galaxy Tab A 10.1, is a popular tablet model released by Samsung. Designed with a 10.1-inch display, it strikes the perfect balance between portability and functionality. It is powered by a robust processor, offers ample storage, and provides high-quality graphics, making it ideal for both entertainment and productivity. Despite its impressive capabilities, users may encounter issues that prompt the need for a reset. Understanding the reasons behind resetting a device can help users decide on the best approach. Why You Might Want to Reset Your Samsung Tablet SM-T580 Strong reasons for resetting your tablet might include: Performance Issues: If your tablet is slow or unresponsive, a reset might speed things up. Software Problems: Bugs or glitches after a software update can sometimes be resolved through a reset. Additionally, if you plan to sell or give away your tablet, performing a reset ensures that your personal information is removed from the device, protecting your privacy. Types of Resets for Your Samsung Tablet SM-T580 Before you proceed with the resetting process, it’s essential to know that there are primarily two types of resets: Soft Reset and Hard Reset. Soft Reset A soft reset is the first step in troubleshooting. It simply involves restarting your tablet, which can solve minor issues without erasing any data. How to Perform a Soft Reset on Samsung Tablet SM-T580 Press and hold the Power button until the Power off option appears on the screen. Tap on Power off and confirm your choice. Wait for the tablet to completely turn off. Once off, press and hold the Power button again until you see the Samsung logo, indicating the tablet is rebooting. This simple action can refresh your device and may resolve minor glitches. Hard Reset A hard reset, or factory reset, is more drastic and will erase all data on your tablet, returning it to its original factory settings. This is useful for clearing persistent issues or preparing the tablet for a new owner. How to Perform a Hard Reset on Samsung Tablet SM-T580 Follow these steps carefully: Method 1: Reset Through Settings Turn on your Samsung Tablet SM-T580. Open the Settings app from your home screen or app drawer. Scroll down and tap on General Management. Select Reset. Tap on Factory Data Reset. Read the information provided; it will show you what will be erased. Scroll down and press the Reset button. If prompted, enter your PIN, password, or pattern. Finally, confirm by tapping on Delete All. This will initiate the resetting process. Your tablet will restart, and it may take a few minutes to complete the factory reset. Method 2: Reset Using the Hardware Buttons If your device is unresponsive, or you cannot access the settings menu, you can perform a hard reset using the hardware buttons. Turn off the tablet completely. If it’s unresponsive, press and hold the Power and Volume Down buttons until it turns off. Once off, press and hold the Power and Volume Up buttons simultaneously until you see the Android logo. Release the buttons. You will now enter the Android Recovery menu. Use the Volume buttons to navigate the menu and highlight the option labeled Wipe data/factory reset. Press the Power button to confirm your selection. Navigate to Yes to confirm the factory reset, and press the Power button again. Once the reset is complete, select Reboot system now. Congratulations! Your Samsung Tablet SM-T580 is now reset to its factory settings. Considerations Before Resetting Your Tablet Before taking the plunge and resetting your device, there are several important considerations to keep in mind. Backup Your Data One of the most crucial steps before proceeding with a hard reset is to back up your data. A factory reset will erase everything on your tablet, including: Apps Photos and videos Contacts Documents Settings To back up your data, follow these steps: Connect your tablet to Wi-Fi. Navigate to Settings. Select Accounts and backup. Tap on Backup and restore. Ensure that Back up my data and Automatic restore are enabled. You may also want to back up your important files to Google Drive or Samsung Cloud. Ensure Adequate Battery Life It’s important to have enough battery life before performing a reset. Ideally, your tablet should be charged to at least 50% to avoid any interruptions during the process. If your battery is low, plug it into a charger before beginning the reset. Common Issues After Resetting While resetting your Samsung Tablet SM-T580 can solve many problems, it may also lead to some new issues. Understanding these can help you prepare. Difficulty in Readding Google Account After a factory reset, you might face issues logging back into your Google account. This can happen if you have not disabled Factory Reset Protection (FRP) before the reset. If you encounter this issue, simply enter the correct Google credentials associated with the device. App Configuration After a reset, you’ll need to reinstall your apps and reconfigure your settings. This may take some time, but it’s an opportunity to start clean and ensure you only install apps you truly need. The Bottom Line Resetting your Samsung Tablet SM-T580 can be an excellent solution for various technical issues or simply for achieving a fresh start. The soft reset is ideal for minor glitches, while the hard reset should be reserved for more serious problems or when you’re ready to part ways with the device. Always follow the precautionary measures provided, such as backing up essential data and ensuring adequate battery life. By understanding the reasons to reset and the methods available, you can confidently tackle any problems that may arise with your Samsung tablet. Embarking on a new journey with your Samsung Tablet SM-T580 after a reset can be quite liberating. You’ll experience enhanced performance, smooth operation, and peace of mind knowing that your personal information is safe should you choose to sell or gift your device. Happy resetting! What is the purpose of resetting my Samsung Tablet SM-T580? Resetting your Samsung Tablet SM-T580 can resolve various performance issues, including lagging, freezing, or application crashes. A reset clears temporary files and stops unused processes, helping in restoring the tablet to its original operating condition. Additionally, a reset can be helpful if you’re experiencing persistent software glitches or if the device is not functioning as intended. In many cases, resetting the device can effectively restore its functionality without the need for professional repairs. What are the different types of resets available for the Samsung Tablet SM-T580? There are primarily two types of resets you can perform on your tablet: a soft reset and a factory reset. A soft reset is a simple restart of the device, which can be accomplished by holding down the power button until the device powers down and then turning it back on. This method is often effective for minor glitches. On the other hand, a factory reset is a more thorough process that wipes all data and settings from the device, restoring it to its original state. This should be considered if you are having significant problems or when preparing the tablet for a new user. Always ensure to backup your data before performing a factory reset. How do I perform a soft reset on my Samsung Tablet SM-T580? Performing a soft reset is quite straightforward. Simply press and hold the Power button located on the right side of your tablet for approximately 10 seconds, or until the screen goes black, and the device powers off. After it turns off, wait a few seconds and then press the Power button again to turn it back on. A soft reset is a quick solution that does not erase any data or applications. It can help refresh the system and fix minor bugs or lag, making it an ideal first step for troubleshooting before considering more drastic measures. What should I do before performing a factory reset? Before initiating a factory reset, it’s essential to back up your data to avoid losing important information. You can back up your files and settings using Samsung Cloud or manually transferring files to a computer or external storage. Ensuring that your contacts, photos, and other critical data are securely saved will help in restoring your tablet to the way you want it post-reset. Additionally, make sure to charge your tablet to at least 50% before performing a factory reset, as the process can take some time and requires a stable power supply. It’s also wise to take note of your Google and Samsung accounts, as you will need these for restoring services and applications after the reset. How do I perform a factory reset on my Samsung Tablet SM-T580? To perform a factory reset on your Samsung Tablet SM-T580, go to the Settings app from the home screen. Scroll down and select “General Management,” then tap on “Reset.” From here, choose “Factory Data Reset,” which gives you an overview of what will be erased from your device. After reviewing the information, you will need to confirm your choice by tapping “Reset.” If you have set a PIN, password, or pattern, you will be prompted to enter it. After confirming, tap “Delete All” to initiate the factory reset. The tablet will restart and begin the reset process, which may take a few minutes. Will a factory reset erase everything on my Samsung Tablet SM-T580? Yes, a factory reset will erase all data, settings, and applications stored on your Samsung Tablet SM-T580. This process restores the device to its original factory settings, thereby removing everything that was saved or downloaded since the initial setup. For this reason, it is highly recommended to back up important files, contacts, and any other data you wish to keep before performing a factory reset. Once the reset is complete, you can restore your files from the backup you created. How can I restore my Samsung Tablet SM-T580 after a factory reset? After you perform a factory reset, you will need to go through the initial setup process, which includes selecting your language, connecting to Wi-Fi, and signing into your Google or Samsung account. This step allows you to access previously installed apps and services linked to your accounts. Once you’ve completed the setup, you can restore data from a backup. If you backed up your files to Samsung Cloud or another service, simply navigate to the respective app to initiate the restoration process. Following these steps will help you get your tablet back to the way it was before the reset. How to enter Samsung Galaxy Tab A 10.1 SM-T580 Recovery Mode, Hard reset / Wipe, Download Mode and Remove forgotten unlock Pattern. Recovery Mode Samsung Galaxy Tab A 10.1 SM-T580 Turn off the device Press and hold Volume UP key + Home Key, while pressing these keys then press and hold Power key for a while Release all key when Android or Samsung logo appear then you will see Android System Recovery Use Volume keys to select Menu Use Power key to Confirm Download Mode or ODIN Mode Turn off the device Press and hold Volume Down key + Home Key, while pressing these keys then press and hold Power key for a while Release all key when you see ODIN Mode / Download Mode Use Volume Up key to continue Use Volume Down key to cancel (Restart the device) Hard reset Samsung Galaxy Tab A 10.1 SM-T580 using External Keys (remove your forgotten pattern unlock) In Recovery Mode, use Volume keys to select wipe data / factory reset Press Power key to confirm Use Volume keys to select Yes — delete all user data Press power key to confirm Use Volume keys to select Reboot system now Press power key to confirm Hard reset using Settings Menu Turn on the device Select Apps Select Settings Select Backup and reset Select Factory data reset Select Reset device Select Erase Everything Warning! If you perform a hard reset, make sure to back up important data. The data can not be recovered after perform a hard reset. If you forgot your unlock pattern, It will remove your forgotten pattern unlock. Tags: download mode, factory reset, hard reset, master reset, odin mode, recovery mode, Samsung Galaxy Tab A 10.1 SM-T580